

7500 MILE PM INTERVALS
(BEGINNING WITH VEHICLES ISSUED IN 2008)

7,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
15,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
22,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
30,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER-REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
37,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
45,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
52,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
60,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS REPLACE ONLY NON-PLATINUM SPARK PLUGS CHECK BRAKE LININGS SERVICE TRANSMISSION AND REPLACE FILTER
67,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES

75,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
82,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
90,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED REPLACE SPARK PLUGS REPLACE AIR FILTER-REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
97,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
105,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES
112,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
120,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK BRAKE LININGS SERVICE TRANSMISSION AND REPLACE FILTER CHECK TIRE PRESSURE AND ROTATE TIRES
127,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
135,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES

7500 MILE PM INTERVALS
(BEGINNING WITH VEHICLES ISSUED IN 2008)

142,500	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED CHECK TIRE PRESSURE AND ROTATE TIRES
150,000	CHANGE OIL AND FILTER CHECK AND FILL ALL FLUID LEVELS LUBE CHASSIS AS REQUIRED REPLACE ONLY NON-PLATINUM SPARK PLUGS REPLACE AIR FILTER REPLACE FUEL FILTER REPLACE EMISSION FILTERS CHECK BRAKE LININGS CHECK TIRE PRESSURE AND ROTATE TIRES